

Dear user!

Thank you for purchase our product(s) Jerry or Jerry+ adapter Rev2. We are very happy to announce that new revision support both all AMIGA and ATARI ST retro computers. All can be easy setup by doing simple reconfiguration step. All interfaces are preconfigured to work with AMIGA computers at startup.

We would be very happy if you enjoy our products and able to issue the positive comment on ebay site, this helps us build strong reputation and raise our motivation to do new „things” also for You.

If you have any comments, suggestions, ideas or would like to ask questions please write to: electronica4you@test.com.pl.

Team electronica4you

Connection and usage

Just plug your adapter to your computers mouse/joystick port (it is not a requirement some users connect it directly to second port and use two mouses game like Lemmings or Settlers). When you plug interface in and turn computer on the adapters LED should blink permanently. It means everything is fine and mouse (or mouse and joystick, depends which adapter you have) can be connected. It doesn't matter when you connect your controller because everything is plug and play.

Some AMIGA models like A600 will require extension adapter which we sold on our actions or you can use your own if you already have. Also Jerry+ requires extension adapter on A2000. Last, all ATARI ST models requires it because under Atari is not enough space. So sorry, it isn't our fault...

Remember to connect mouse with PS2 protocol included, it could be with direct USB connection or with use PS2->USB adapter! We have a list of 100% working mouses tested by our users, if you would like to know please write to us (we don't attach the list here because it is changing almost everyday).

If you got Jerry+ adapter you can also connect Joystick to second port of your adapter. In this adapter you can choose which controller you want to use. When you click left mouse button you select mouse as main controller, if you press joystick button you select joystick as controller. Really simple, isn't?

LED indicator is your friend, when proper mouse is connected (or selected) the LED blinks once, if joystick it blinks twice. ***Have fun!***

Reconfiguration step

All adapters before shipment are tested on our computers. Then preconfigured to AMIGA. Anytime you can reconfigure your interface to use with ATARI or AMIGA in simple way:

- Connect your adapter to computer and turn it on
- Make sure that connected mouse is proper (LED blinking once)
- Then turn off computer and press and hold LEFT (for ATARI) and RIGHT (for AMIGA) mouse button
- Turn on your computer (with still holding button)
- After about 1 second, when mouse was detected, click fastly 5 times opposite button
- Thereafter adapter LED should off and then you can release holded button
- Now adapter is preconfigured which is shown on LED (1 blink for AMIGA, 2 blinks for ATARI)
- Afterwards everything backs to normal and adapter can be used again